





EXPAND IO

3.3V	5V
HTXCN	5V
HTXCP	GND
HTXOP	HTXON
GND	HTX1P
HTX1N	HTX2P
HTX2N	GND
HSDA	HSCL
3.3V	HCEC
HHPD	GND
TVOUT0	MINCIN1P
MINCIN1N	FMINL
GND	FMINR
LINEOUTLN	LINEOUTLP
LINEOUTRN	GND
LINEOUTRP	GPADC1
LRADC	GND
MBIAS	MICIN2N
MICIN2P	TVIN1
GND	TVIN0

